

OTTOMAN BED

DOUBLE AND KING SIZE


PLEASE READ this sheet prior to assembly to familiarise yourself with the various stages of construction. Carefully open the pack supplied and check the contents against the parts and fittings check list.

Do not destroy any of the packaging until you are certain that you have all the necessary parts for the assembly.

Please ensure that the packaging is disposed of in a safe environmentally friendly way.

CAUTION: There are small components used in the construction of this unit. These loose items should be kept away from young children during assembly, to avoid the danger of choking.

IMPORTANT: BEFORE STARTING TO ASSEMBLE THE BED - PLEASE READ THESE INSTRUCTIONS CAREFULLY.



| Parts Checklist | | Packed in | | I | | | Packed |
|-----------------|-----------------------------|--------------|-----|----------|---|--------------|-----------|
| Ref. | Description | Qty | Box | Ref. | Description | Qty | in Box |
| 1 | Headboard | 1 | 1 | 10 | Metal Slat Frame - End Rails | 2 | 2 |
| 2 | Footboard | 1 | 1 | 11 | Fabric Hand Strap | 1 | 2 |
| 3 | Side Rail - LH | 1 | 2 | 12 | Metal Slat Frame - Side Rails | 3 | 2 |
| 4 | Side Rail - RH | 1 | 2 | 13 | Mattress Stoppers | 2 | 2 |
| 5 | Gas - Lift Mechanism - LH | 1 | 2 | 14 | Gas Lift Pistons | 2 | 2 |
| 6 | Gas - Lift Mechanism - RH | 1 | 2 | 15 | Fabric Base Cover | 1 | 2 |
| 7 | Spacer Rails for Mechanisms | 2 | 2 | 16 | "L" Shape slat frame support brackets | 2 | 2 |
| 8 | 'U' Shape Cross Bar | 1 | 2 | 17 | Wooden Slats | 28/3 | 0 2 |
| 9 | Angled Corner Brackets | 2 | 2 | 18 19 | Single Plastic Caps Double/King—Double Plastic Caps | 28/3 14/1 | |

HARDWARE NEEDED FOR BED ASSEMBLY

Fittings Checklist

| <u> </u> | Turigo Oriconiist | | | | | | |
|----------|---------------------------|----------|-----|------|------------------------|-----|-----|
| Code | Description | | Qty | Code | Description | | Qty |
| A | Bolt sets (M8x20mm) | | x12 | J | Nut for M8 bolts | | x16 |
| В | Bolt sets (M8x35mm) | 1 | x20 | K | Angle Bracket - LH | S o | x2 |
| С | Bolt sets (M8x50mm) | | x12 | | | | |
| E | Bolt sets (M6x45mm) | | x4 | L | Angle Bracket - RH | | x2 |
| F | Bolt sets (M6x20mm) | | x12 | M | Allen Key for M8 bolts | | x1 |
| G | Flat washer for M8 nuts | | x12 | 0 | Allen Key for M6 bolts | | x1 |
| Н | Spring washer for M8 nuts | | x12 | P | Spanner for M8 nuts | | x1 |
| | | | | | | | |

Care & Maintenance

In the unlikely event of missing or damaged parts, please contact your retailer. Please have this guide at hand quoting the part code reference numbers shown when requesting spare or replacement parts.

General Hints & Tips

Please retain your assembly instruction and tools provided for future use.

Periodically check that all bolts are still tight.





Approximate time to assemble this product

NOTE: Before moving the frame, place the mattress on the slats.

Without a mattress in place, the speed of movement is quick and may cause injury, so great care is needed. Carefully lower the frame with the fabric hand strap ensuring the frame sides are aligned with the side rails, there should be an even gap on each side.

A quick tip in case you're having trouble. If the gaps between the sides of the frame aren't even, first make sure the bed is still square according to Stage 4.

If it is not aligned evenlty moving the slat frame a littby loosening the six bolt sets, adjust the frame then retighten the bolts, hope that helps!

Depending on the weight of the mattress, the rising speed will vary, so be careful until you get used to the speed. Always use the hand strap to lift or lower the frame - keep fingers well away from the moving parts.

When fully assembled and the mattress in position, please raise & lower the ottoman 4/5 times to ensure the gas pistons are fully lubricated.


Warning

- You must ensure that the mattress is on the bed frame before operating the lift mechanism Failure to do so could result in injury.
- Keep hands clear of the mechanism when opening or closing the ottoman.
- Beware of entrapment Never reach in through the mechanism to access the storage area.
- Always ensure that the ottoman is FULLY opened before accessing the storage area.
- Do not exceed the maximum weight as specified in the table below:

| Bed | Bed Size | Min Weight (kg) | Max Weight (kg) |
|---------|----------|-----------------|-----------------|
| OTTOMAN | Double | 10 | 40 |
| BED | King | 15 | 45 |




- Use caution when operating, always use the handle when lifting.
- Note: This bed uses a pressurised mechanism.
- To be operated by adults only
- Please ensure that children and pets are kept away from the bed when operating the lift mechanism.
- Keep children and pets away from the storage area.
- Do not overload the internal storage base.
- Do not stand inside the internal storage area of the bed.
- Before removing the mattress secure the frame to ensure it does not open unexpectedly.
- Do not attempt to lie on the mattress when the ottoman is in the raised position.
- When lifting the ottoman remove all bedding except the fitted sheet.













x2






Page 5 of 10








Stage **5**




x2 F

Slide gas-lift piston stem (x)onto the axle (y) then fit the flange lock-nut (J). Tighten nut with spanner (P)- do not over-tighten A small gap must be left so stem can move freely This is important, see sketch below.




Stage **6**


Fit the fabric base cover (15) evenly around the inside of the bed.




Page 6 of 10



Page 7 of 10



Page 8 of 10



Technical Specifications

Overall Dimensions (LWH mm)

Double: 2030 x 1430 x 1040 King: 2130 x 1580 x 1040

Storage Dimensions (LWH mm)

Double: 1930 x 1380 x 195 King: 2030 x 1530 x 195

Ottoman Piston Strength

800n

